

Under ground (UG) cables - construction - materials - types - joints - testing

Objectives: At the end of this lesson you shall be able to

- define UG cable
- explain the construction of UG cables
- list and state the insulating materials used in cables
- list out and state the types of UG cables used for 3 phase service
- state the types of cable joints and laying methods
- explain the faults and testing procedures of cables.

Under Ground (UG) cables

"A cable so prepared that it can withstand pressure and can be installed below the ground level and normally two or more conductors are placed in an UG cable with separate insulation on each conductor"

Electric power can be transmitted (or) distributed either by over-head lines system or by underground cable system. The underground cable system have several advantage, such

Advantages

- Less chance to damage through storms or lightning.
- Low maintenance cost.
- Less chances of fault.
- Not affected by man- made problems like sabotage, strike etc.
- Voltage regulation in UG cables system is much better, because they have less inductive losses.
- Better general appearance of area compared to O.H lines.

Disadvantages

However, their major draw back/ disadvantages are

- Initial cost of UG cable system is heavy.
- The cost of joints are more.
- Introduce insulation problems at high voltages compared with O.H lines.

For these reasons UG cables are employed where it is impracticable to use O.H lines like (i) thickly populated areas, where municipal authorities prohibit O.H lines for the reason of safety.

- ii Around plants
- iii In Substations,
- iv Where maintenance conditions do not permit the use of O.H construction.

The UG cable were used many years for distribution of electric power in congested urban areas to low and medium voltages. Then with improvement and development of design, the manufactures have made it possible to use

at high voltage transmission of electric power for same moderate distances.

General construction of UG cables

An underground cable essentially consists of one or more conductors covered with suitable insulation and surrounded by a protecting cover.


Necessity requirements for cables

In general, a cable must fulfill the following necessary requirements.

- i The conductor used in cables should be tinned stranded copper or aluminum of high conductivity. (Strands of cable gives flexibility and carry more current).
- ii The size of the conductor should be selected, so that the cable carries the desired load current without overheating and limits the voltage drop to a permissible value.
- iii The cable must have proper thickness of insulation to ensure the safety and reliability for the designed voltage.

General construction of UG cables

- iv The cable must be provided with suitable mechanical protection so that it may withstand the rough use in laying it.
- v The materials used in cables should be with complete chemical and physical stability throughout.



Construction of Cables

Fig 1 shows the general construction of a 3-core cable. The various parts are:

- i) **Cores or conductors:** A cable may have one or more than one core (conductor) depending upon the type of service for which it is intended. For instance, the 3-

conductor cable shown in Fig 1 is used for 3-phase service. The conductors are made of tinned copper or aluminium and are usually stranded in order to provide flexibility to the cable and having high conductivity.

- ii **Insulation:** Each core or conductor is provided with a suitable thickness of insulation, the thickness of layer depending upon the voltage to be withstood by the cable. The commonly used materials for insulation are impregnated paper, varnished cambric or rubber mineral compound. Petroleum jelly is applied to the layers of the cambric to prevent damage.
- iii **Metallic sheath:** In order to protect the cable from moisture, gases or other damaging liquids (acids or alkalies) in the soil and atmosphere, a metallic sheath of lead or aluminium is provided over the insulation as shown in Fig 1. The metallic sheath is usually a lead or lead alloy.
- iv **Paper Belt:** Layer of impregnated paper tape is wound round the grouped insulated cores. The gap in the cores is filled with fibrous insulating material (jute etc.)
- v **Bedding:** Over the metallic sheath is applied a layer of bedding which consists of a fibrous material like jute or hessian tape. The purpose of bedding is to protect the metallic sheath against corrosion and from mechanical injury due to armouring.
- vi **Armouring:** Over the bedding, armouring is provided which consists of one or two layers of galvanized steel wire or steel tape. Its purpose is to protect the cable from mechanical injury while laying it and during the course of handling. Armouring may not be done in the case of some cables.
- vii **Serving:** In order to protect armouring from atmospheric conditions, a layer of fibrous material (like jute) similar to bedding is provided over the armouring. This is known as serving.

It may not be out of place to mention here that bedding, armouring and serving are only applied to the cables for the protection of conductor insulation and to protect the metallic sheath from mechanical injury.

Insulating materials for cables

The satisfactory operation of a cable depends to a great extent upon the characteristics of insulation used. Therefore, the proper choice of insulating material for cables is of considerable importance. In general, the insulating material used in cables should have the following properties:

- i) High insulation resistance to avoid leakage current.
- ii) High dielectric strength to avoid electrical breakdown of the cable.
- iii) High mechanical strength to withstand the mechanical handling of cables.
- iv) Non-hygroscopic i.e. it should not absorb moisture from air or soil. The moisture tends to decrease the insulation resistance and hastens the breakdown of the cable.

In case the insulating material is hygroscopic, it must be enclosed in a waterproof covering like lead sheath.

- v) Non-inflammable
- vi) Low cost compared to O.H. system.
- vii) Unaffected by acids and alkalies to avoid any chemical action.

The type of insulating material to be used depends upon the purpose for which the cable is required and the quality of insulation to be aimed at.

The principal insulating materials used in cables are

- (i) Rubber
- (ii) Vulcanized India rubber
- (iii) Impregnated paper
- (iv) Varnished cambric and
- (v) Polyvinyl chloride.

1 Rubber: Rubber may be obtained from milky sap of tropical trees or it may be produced from oil products. It has relative permittivity varying between 2 and 3, dielectric strength is about 30 KV/mm and resistivity of insulation is $10^{17} \Omega \text{ cm}$.

It suffers from some major drawbacks viz readily

- (i) absorbs moisture
- (ii) maximum safe temperature is low (about 38°C)
- (iii) soft and liable to damage due to rough handling and ages when exposed to light.

Therefore, pure rubber cannot be used as an insulating material.

2 Vulcanised Indian Rubber (V.I.R.) : It is prepared by mixing pure rubber with mineral matter such as zinc oxide, red lead etc. and 3 to 5% of sulphur. The compound so formed is rolled into thin sheets and cut into strips. The rubber compound is then applied to the conductor and is heated to a temperature of about 150°C . The whole process is called **vulcanization** and the product obtained is known as **Vulcanized Indian Rubber**.

Advantages: Vulcanised India rubber has greater mechanical strength, durability and water resistant property than pure rubber.

Disadvantages: Its main drawback is that sulphur reacts quickly with copper. So, cables using VIR insulation must have tinned copper conductor. The VIR insulation is generally used for low and moderate voltage cables.

3 Impregnated paper: It consists of chemically pulped paper made from wood chippings and impregnated with some compound such as paraffin or naphthenic material.

Advantages:

- (i) Low cost
- (ii) Low capacitance
- (iii) High dielectric strength and
- (iv) High insulation resistance.

Disadvantages:

- (i) The paper is hygroscopic and even if it is impregnated with suitable compound
- (ii) It absorbs moisture and thus lowers the insulation resistance of the cable.

For this reason, paper insulated cables are always provided with some protective covering and are never left unsealed. If it is required to be left unused on the site during laying, its ends are temporarily covered with wax or tar.

Since the paper-insulated cables have the tendency to absorb moisture, they are used where the cable route has a few joints. For instance, they can be profitably used for distribution at low voltages in congested areas where the joints are generally provided only at the terminal apparatus. However, for smaller installations, where the lengths are small and joints are required at a number of places, VIR Cables will be cheaper and durable than paper insulated cables.

4 Varnished cambric: It is a cotton cloth impregnated and coated with varnish. This type of insulation is also known as empire type. The cambric is lapped on to the conductor in the form of tape and its surface is coated with petroleum jelly compound to allow for the sliding of one turn over another as the cable is bent. As the varnished cambric is hygroscopic, therefore, such cables are always provided with metallic sheath. Its dielectric strength is about 4 KV/mm and permittivity is 2.5 to 3.8.

5 Polyvinyl chloride (PVC): This insulating material is a synthetic compound. It is obtained from the polymerization of acetylene and is in the form of white powder. For obtaining this material as a cable insulation, it is compounded with certain materials known as plasticiser which are liquids with high boiling point.

Advantages:

- (i) It has high insulation resistance
- (ii) Good dielectric strength
- (iii) Mechanical toughness over a wide range of temperature.

This type of insulation is preferred over VIR in extreme environmental conditions such as in cement factory or chemical factory.


Classification of cables

Cables for underground service may be classified in two ways according to (i) the type of insulating material used in their manufacture (ii) the voltage for which they are manufactured. However, the later method of classification is generally preferred as

- (i) Low-tension (L.T) cables – upto 1100 V
- (ii) High-tension (H.T) cables – upto 11,000 V
- (iii) Super-tension (S.T) cables – from 22 KV to 33 KV
- (iv) Extra high-tension (E.H.T) cables – from 33 to 66 KV
- (v) Extra super voltage cables – beyond 132 KV

A cable may have one or more than one core depending upon the type of service for which it is intended. It may be (i) single-core (ii) two-core (iii) three-core (iv) four-core etc. For a 3-phase service, either 3-single core cables or three-core cable can be used depending upon the operating voltage and load demand.

Fig 2 shows the constructional details of a single-core low tension cable. The cable has ordinary construction because the stresses developed in the cable for low voltages (upto 6600 V) are generally small. It consists of one circular core of tinned stranded copper (or aluminium) insulated by layers of impregnated paper. The insulation is




surrounded by a lead sheath which prevents the entry of moisture into inner parts. In order to protect the lead sheath from corrosion, an overall serving of compounded fibrous material (jute etc.) is provided. Single-core cables are not usually armoured in order to avoid excessive sheath losses. The principal advantages of single-core cables are simple construction and availability of large copper section.

Cables for 3-Phase Service

In practice, underground cables are generally required to deliver 3-phase power. For the purpose, either three-core cables or three single core cables may be used. For voltages upto 66 KV, 3-core cable (i.e. multi-core construction) is preferred due to economic reasons. The following types of cables are generally used for 3-phase service.

1. Belted cables – upto 11 KV
2. Screened cables – from 22 KV to 66 KV
3. Pressure cables – beyond 66 KV

1. Belted cables



These cables are used for voltages upto 11 KV but in extraordinary cases, their use may be extended upto 22 KV. Fig 3 shows the constructional details of a 3-core belted cables. The cores are insulated from each other by layers of impregnated paper.


Another layer of impregnated paper tape called paper belt is wound round the grouped insulated cores. The gap between the insulated cores is filled with fibrous insulating material (jute etc.) The belt is covered with lead sheath to protect the cable against ingress of moisture and mechanical injury.

The belted type construction is suitable only for low and medium voltages as the electrostatic stresses developed in the cables for these voltages are more or less radial i.e. across the insulation. However, for high voltages (beyond 22 KV), the tangential stresses also become important.

2. Screened cable

These cables are meant for use upto 33 KV but in particular cases their use may be extended to operating voltages upto 66 KV. Two principal types of screened cables are H-type cable and S.L. type cables.

(i) **H-type cables.** This type of cable was first designed by H. Horchstadter and hence the name. Fig 4 shows the constructional details of a typical 3-core, H-type cable. Each core is insulated by layers of impregnated paper. The insulation on each core is covered with a metallic screen which usually consists of a perforated aluminium foil.



The cable has no insulating belt but lead sheath, bedding, armouring and serving follow as usual. As all the four screens (3 core screens and one conducting belt) and the lead sheath are at earth potential.

Advantages:


- The possibility of air pockets or voids in the dielectric is eliminated
- The metallic screen increase the heat dissipating power of the cable

(ii) **S.L. type cables** Fig 5 shows the constructional details of 3-core S.L (**separate lead**) type cable. It is basically H-type cable but the screen round each core insulation is covered by its own lead sheath. There is no overall lead sheath but only armouring and serving are provided.

The S.L type cables have two main advantages over H-type cables.

- The separate sheaths minimize the possibility of core-to-core breakdown.
- Bending of cables become easy due to the elimination of overall lead sheath.

The disadvantage is that the three lead sheaths of S.L. cable are much thinner than the single sheath of H-cable



Limitations of solid type cables

All the cables of above constructions are referred to as solid type cables because solid insulation is used and no gas or oil circulates in the cable sheath. The voltage limit for solid type cables is 66 KV due to the following reasons:

- As a solid cable carries the load, its conductor temperature increases and the cable compound (i.e. insulating compound over paper) expands. This action stretches the lead sheath which may be damaged.
- When the load on the cable decreases, the conductor cools and a partial vacuum is formed within the cable sheath. If the pinholes are present in the lead sheath, moist air may be drawn into the cable. The moisture reduces the dielectric strength of insulation and may eventually cause the breakdown of the cable.
- In practice, voids are always present in the insulation of a cable. Modern techniques of manufacturing have resulted in void free cables. However, under operating conditions, the voids are formed as a result of the differential expansion and contraction of the sheath and impregnated compound.

3. Pressure cables

For voltages beyond 66 KV, solid type cables are unreliable because there is a danger of breakdown of insulation due to the presence of voids. When the operating voltages are greater than 66 KV, pressure cables are used. In such cables, voids are eliminated by increasing the pressure of compound and for this reason they are called pressure cables. Two types of pressure cables viz oil filled cables and gas pressure cables are commonly used.

(i) **Oil filled cables.** In such type of cables, channels of ducts are provided in the cable for oil circulation. The oil under pressure (it is the same oil used for impregnation) is kept constantly supplied to the channel by means of

external reservoirs placed at suitable distances (say 500 m) along the route of the cable.

Oil under pressure compresses the layers of paper insulation and is forced into any voids that may have formed between the layers. Due to the elimination of voids, oil-filled cables can be used for higher voltages, the range being from 66 KV upto 230 KV.


Oil-filled cables are of three types viz.

- (i) Single-core conductor channel
- (ii) Single-core sheath channel and
- (iii) Three-core filler-space channels.

(i) Single-core Conductor channel


Fig 6 shows the constructional details of a single-core conductor channel, oil-filled cable. The oil channel is formed at the centre by stranding the conductor wire around a hollow cylindrical steel spiral tape. The oil under pressure is supplied to the channel by means of external reservoir. As the channel is made of spiral steel tape, it allows the oil to percolate between copper strands to the wrapped insulation.

The oil pressure compresses the layers of paper insulation and prevents the possibility of void formation. The disadvantage of this type of cable is that the channel is at the middle of the cable which is at full voltage w.r.t earth, so that a very complicated system of joints is necessary.




(ii) Single-core sheath channel (Fig 7)

In this type of cable, the conductor is solid similar to that of solid cable and is paper insulated. However, oil ducts are provided in the metallic sheath.



In the 3-core oil-filled cable shown in Fig 8, the oil ducts are located in the filler space. These channels are composed of perforated metal-ribbon tubing and are at earth potential.




Advantages

- (a) Formation of voids and ionization are avoided.
- (b) Allowable temperature range and dielectric strength are increased.
- (c) If there is leakage, the defect in the lead sheath is at once indicated and the possibility of earth faults is decreased.

Disadvantages

- (a) High initial cost and complicated system of laying
- (ii) **Gas pressure cables.** The voltage required to set up ionization inside a void increases as the pressure is increased. Therefore, if ordinary cable is subjected to a sufficiently high pressure, the ionization can be altogether eliminated. At the same time, the increased pressure produces radial compression which tends to close any voids. This is the underlying principle of gas pressure cables.

Fig 9 shows the section of external pressure cable designed by Hockstadter, Vogal and Bowden. The construction of the cable is similar to that of an ordinary solid type except that it is of triangular shape and thickness of lead sheath is 75% that of solid cable. The triangular section reduces the weight and gives low thermal resistance but the main reason for triangular shape is that the lead sheath acts as a pressure membrane. The sheath is protected by a thin metal tape. The cable is laid in a gas-tight steel pipe.



The pipe is filled with dry nitrogen gas at a pressure of 12 to 15 atmospheres. The gas pressure produces radial compression and closes the voids that may have formed between the layers of paper insulation.

Advantages:

- a) Cables can carry more load current
- b) Operate at higher voltages than a normal cable.

c) Maintenance cost is small and the nitrogen gas helps in quenching any flame.

Disadvantages:

The overall cost is very high.

Further the cables are also classified according to their insulation system as under:

PVC insulated cables	(Poly vinyl chloride)
MI cables	(Mineral insulation)
PILC cables	(Paper insulated lead covered)
XLPE cables	(Cross linked poly ethylene)
PILCDA cables	(Paper insulated lead covered double tape armoured)

The specification of underground cables

The cables shall carry the following information either labelled or stenciled on the reel or drum or container.

- 1 Reference to the Indian Standard; for example Ref. IS 694-1977.
- 2 Manufacturer's name, brand name or trademark.
- 3 Type of cable and voltage grade.
- 4 Number of cores.
- 5 Nominal cross-sectional area of conductor.
- 6 Cable code.
- 7 Colour of cores (in case of single core cables)
- 8 Length of cable on the reel, drum or coil
- 9 Number of lengths on the reel, drum or coil (if more than one).
- 10 Direction of rotation of drum (by means of arrow).
- 11 Approximate gross weight.
- 12 Country of manufacturing.
- 13 Year of manufacture.

Fig 10 shows the paper insulated 3 phase 3 ½ core cable.

UG cables laying method


The reliability of the underground cable (UG) installation depends upon the proper laying and attachment of fittings (i.e) cable and boxes, joints, branch connectors etc.

Methods of laying of UG cables

The following are the methods of laying underground cables

- 1 Laying direct in ground
- 2 Laying in ducts
- 3 Laying on racks in air.
- 4 Laying on racks inside a cable tunnel.
- 5 Laying along buildings or structures.

Fig 10



The choice of any of the systems given above depends on

- (i) The actual installation conditions
- (ii) Initial cost of laying
- (iii) Maintenance and repair charges
- (iv) Desired care in replacement of any cable or adding new cables for the future.

As far as possible cable should be laid along the roads and streets. Power and communication cables should cross at right angles.

During the preliminary stages of laying the cable, consideration should be given to a proper location of the joints position so that when the cable is actually laid, the joints are made in the most suitable places.

As far as possible water logged locations, carriage ways, pavements, proximity to telephone cables, gas or water mains in accessible places, ducts pipes, racks etc shall be avoided for joint position.